




CONSTRUCTION OF STRAW BALE BARRIER




1. EXCAVATE THE TRENCH.





2. PLACE AND STAKE STRAW BALES.



3. WEDGE LOOSE STRAW BETWEEN BALES.




4. BACKFILL AND COMPACT THE EXCAVATED SOIL.




PROPERLY INSTALLED STRAW BALE (CROSS SECTION)


1. SET POSTS AND EXCAVATE A 4" x 4" TRENCH UPSLOPE ALONG THE LINE OF POSTS.




2. ATTACH WIRE FENCING TO THE POSTS.




3. ATTACH THE FILTER FABRIC TO THE WIRE FENCE AND EXTEND IT INTO THE TRENCH.




4. BACKFILL AND COMPACT THE EXCAVATED SOIL.




EXTENSION OF FABRIC AND WIRE INTO THE TRENCH




SET THE STAKES.





2. EXCAVATE A 4" x 4" TRENCH UPSLOPE ALONG THE LINE OF STAKES.



3. ATTACH FILTER MATERIAL TO STAKES AND EXTEND IT INTO THE TRENCH.



4. BACKFILL AND COMPACT THE EXCAVATED SOIL.



DRAINAGEWAY INSTALLATION (FRONT ELEVATION)

EROSION CONTROL DEVICES



To: Contractors

From: Public Works, Engineering

Subject: Erosion Control Devices and Rock Placement

Once foundation is in Rock will be placed from garage to Curb line. It will be maintain with rock until concrete driveway is poured. This is how all personnel and deliveries will access property

